

**Track Assembly Guide.**

Updated 10/25/2006.

Print this out and get the kit.



Image of Tracks.

**Step 1.**

Align two track modules as shown in Figure 1 and insert a nylon rivet fastener. Note, do not attempt to push this in with your thumb. It will hurt.



Figure 1.

**Step 2.**

Tilt the assembly up and push down to fully engage the rivet fastener.



Figure 2.

**Step 3.**

Insert a polypropylene rod through the open end as shown.



Figure 3.

**Step 4.**

Insert a rivet fastener to hold the polypropylene rod in place.



Figure 4.

**Step 5.**

Continue until the track is the length required. Every link is a master link, but replacement of the nylon fasteners is recommended if they are removed.



Figure 5.